

Dispenser Loading Instructions Revolution™



80302	-	Translucent
80303	-	Red
80304	-	Green
80305	-	Blue
80306	-	White

- To refill, simply unlock and open the access cover.
- The brake bar mechanism displayed on bottom left hand side ensures that each roll is fully used before the next roll is commissioned, so you only need to replace empty cores.
- Each EcoSoft Toilet Roll has its own individual wrapper, which must be left on when loading into the dispenser. A fold should be made at the wrapper end and positioned to the outer rim of the dispenser, to enable the fold to present itself to the user when locked into position.

